

Türkantriegel



I-800/*



I-801/*



I-802/*



I-803/*



I-804/*



I-805/*

* = Länge des Treibriegels in mm

Bitte Stulpbreite angeben.